

Topaz Systems, Inc. E-Tether Replacement Documentation

Topaz Systems, Inc.
650 Cochran Street, Unit 6
Simi Valley, CA, 93065
©1995-2006, all rights reserved, US patent 6,307,955, and pending

www.topazsystems.com
tech support: 805 520-8286
support@topazsystems.com

1. Locate the bay where the E-Tether pen attaches to the Topaz Tablet.



2. Remove screw which secures the bay cover to the Topaz Tablet with a Phillips screwdriver. This cover prohibits the pen from being removed from the pad.



3. Remove the bay cover and now you can remove the 1/8" plug from the Topaz Tablet and replace it with a new E-Tether Pen.



After the E-tether pen is replaced, replace the bay's cover and screw to secure.

For more information regarding products and support
Email: support@topazsystems.com
Phone: (805) 520-8286

www.topazsystems.com
650 Cochran Street, Unit 6, Simi Valley, CA, USA, 93065
Phone: 805 520-8282; Fax: 805 520-0867