



Installation Guide

Right-Angle Strain Relief Cable

Copyright © 2020 Topaz Systems Inc. All rights reserved.

For Topaz Systems, Inc. trademarks and patents, visit www.topazsystems.com/legal.

Overview

This manual will help you install your right-angle strain relief USB cable. This cable can be used with model numbers T-LBK750, T-LBK755, T-LBK766, and T-LBK57GC with model suffixes “-BHSB-R”, “-BBSB-R”, or “-BHSX-R.”

Steps

1. Unplug the signature pad’s USB cable and remove the cover over the serial port so that your pad looks like the picture below. Flip your signature pad over and remove the two screws that are holding the rear vertical pen holder in place. Save these screws to be used in again in step 4. Place your signature pad with the LCD facing upward.



2. Put the USB cable into the strain relief bracket and plug back into the pad.



3. Fasten the strain relief in place with the 2 screws provided (4-40 x 3/16" flat head).



4. Re-attach the vertical pen holder removed in step 2.

